




























## Weller Digital Soldering Station












WSD 81 Soldering station

### Tips for the WSP 80, WSP 80FE and MPR 80 Soldering pencils:\*

								
LT 1 Ø 0,25 mm Round tip 5 44 435 99	LT 1L Ø 0,2 mm Round tip 5 44 423 99	LT 1S Ø 0,2 mm Round tip 5 44 436 99	LT AS Ø 1,6 mm Round tip 5 44 404 99	LT CS Ø 3,2 mm Round tip 5 44 411 99	LT H 0,8 mm Chisel tip 5 44 437 99	LT F 1,2 mm Chisel tip 5 44 408 99	LT K 1,2 mm Chisel tip 5 44 438 99	LT A 1,6 mm Chisel tip 5 44 440 99
								
LT L 2,0 mm Chisel tip 5 44 414 99	LT B 2,4 mm Chisel tip 5 44 405 99	LT C 3,2 mm Chisel tip 5 44 407 99	LT M 3,2 mm Chisel tip 5 44 415 99	LT D 4,6 mm Chisel tip 5 44 409 99	LT 4 Sloped tip 5 44 439 99	LT GW Ø 3,2 mm Sloped tip 5 44 410 99	LT S Ø 0,4 mm Conical tip 5 44 406 99	LT 1LX Ø 0,2 mm Bent tip 5 44 424 99
								
LT HX 0,8 mm Bent tip 5 44 420 99	LT 4X Ø 1,2 mm Bent tip 5 44 428 99	LT AX Ø 1,6 mm Bent tip 5 44 427 99	LT 1X Ø 2,0 mm Bent tip 5 44 425 99	LT 1SLX Ø 2,0 mm Bent tip 5 44 426 99	LT ALX 1,6 mm Bent tip 5 44 443 99	LT BX 2,4 mm Bent tip 5 44 442 99	LT Adaptor For SMD tips 5 44 417 99	LT BB 2,4 mm sloped tip 5 44 444 99

### Tips for the WSP 150 Soldering pencil:

								
LT CC 3,2 mm sloped tip 5 44 445 99	LT Measuring tip 5 44 416 99	LHT D 5 mm Chisel tip 5 44 452 99	LHT E 7 mm Chisel tip 5 44 451 99	LHT F 10 mm Chisel tip 5 44 450 99	LHT DX 5 mm Chisel tip 5 44 462 99	LHT EX 7 mm Chisel tip 5 44 461 99	LHT FX 10 mm Chisel tip 5 44 460 99	LHT Calibration tip 5 44 453 99

\* Different tips for lead free applications see Electronics Price List or on [www.cooperhandtools.com/europe](http://www.cooperhandtools.com/europe)